# Mersel Install Guide Hybrid Smart Lock



Digilock


000

QR Code Sticker Placement	
QR Code Overview & IMPORTANT: Before Installation	3
Surface Keypad Installation - Surface Mount: For Door Thickness up to 25mm	
Required Components & Installation	
3-Hole Template	
Recommended Tools for Installation	
Installation–Concealed Plate	
4-Hole Template–Concealed Plate	7
Recess Keypad Installation - Recess Mount: For Door Thickness between 10-25mm	
Required Components & Installation	
Recess Mortise Template	
Recommended Tools for Installation	
Installation–Concealed Plate	
4-Hole Template-Concealed Plate	11
Surface RFID Installation - Surface Mount: For Door Thickness up to 25mm	
Required Components & Installation	
3-Hole Template	
Recommended Tools for Installation	
Installation–Concealed Plate	
4-Hole Template–Concealed Plate	15
Recess RFID Installation - Recess Mount: For Door Thickness between 10-25mm	11
Required Components & Installation	
Recess Mortise Template Recommended Tools for Installation	
Installation–Concealed Plate	
Mortise Template–Concealed Plate	
Surface Keypad Installation - Surface Mount: For Door Thickness less than 10mm	20
Required Components & Installation 3-Hole Template	
Recommended Tools for Installation	
Installation–Concealed Plate	
4-Hole Template–Concealed Plate	
<b>Recess Keypad Installation</b> - Recess Mount: For Door Thickness less than 10mm	
Required Components & Installation	24
Recess Mortise Template	
Recommended Tools for Installation	
Installation–Concealed Plate	
Recess Mortise Template–Concealed Plate	
Surface RFID Installation - Surface Mount: For Door Thickness less than 10mm	
Required Components & Installation	28
3-Hole Template	
Recommended Tools for Installation	
Installation–Concealed Plate	
4-Hole Template–Concealed Plate	
Recess RFID Installation - Recess Mount: For Door Thickness less than 10mm	-
Required Components & Installation	
Recess Mortise Template	
Recommended Tools for Installation	
Installation–Concealed Plate	
Mortise Template–Concealed Plate	

#### **QR CODE STICKER PLACEMENT**


A QR Code sticker is provided for initial setup to initialize locks to the DigiLink system.

#### **QR** Code Overview




# IMPORTANT: Before Installation


A pair of identical QR code stickers unique to each lock are attached to the back of the front unit. Before installation, one of these stickers must be attached to the lock's battery pack so that it may be easily scanned when adding the lock to DigiLink.



1. Before installation, remove the partially attached QR code sticker located on the back of the front unit.



- 2a. Remove the tab from the back of the QR code sticker.
- <sup>111.</sup> 2b. Attach the QR code sticker to the front of the battery pack in the location shown above.




 Make sure the QR code sticker is securely attached to the battery pack and visible when the lock is installed.


### SURFACE KEYPAD INSTALLATION

Surface Mount: For Door Thickness up to 25mm


#### **Required Components**




#### Power Cable Connection





Pull the power cable through the door opening as shown.




Insert through the rear opening of the battery base as shown.












**INSTALL GUIDE** Hybrid Smart Lock

#### **3-HOLE TEMPLATE**


Versa™







1 - 15/16" Deep Socket Driver\*




1 - Adjustable Wrench\*



#### SURFACE KEYPAD INSTALLATION-CONCEALED PLATE

Surface Mount: For Door Thickness up to 25mm


#### **Required Components**




#### Power Cable Connection




Pull the power cable through the door opening as shown.





Insert through the rear opening of the battery base as shown.



Connect the power cable as shown above.









INSTALL GUIDE Hybrid | Smart Lock


#### 4-HOLE TEMPLATE-CONCEALED PLATE

Versa™



Recommended Tools for Installation (\*Not Included)






#### **RECESS KEYPAD INSTALLATION**


Recess Mount: For Door Thickness between 10mm-25mm

#### **Required Components**




Power Cable Connection


Pull the power cable through the door opening as shown.





Insert through the rear opening of the battery base as shown.




Connect the power cable as shown above.









# **RECESS MORTISE TEMPLATE**




Recommended Tools for Installation (\*Not Included)





1 - 15/16" Deep Socket Driver\*




1 - Adjustable Wrench\*




#### **RECESS KEYPAD INSTALLATION-CONCEALED PLATE**

Recess Mount: For Door Thickness between 10mm-25mm


#### **Required Components**




#### Power Cable Connection




Pull the power cable through the door opening as shown.





Insert through the rear opening of the battery base as shown..



Connect the power cable as shown above.










Versa™

#### RECESS MORTISE TEMPLATE-CONCEALED PLATE




#### Recommended Tools for Installation (\*Not Included)





1 - 15/16" Deep Socket Driver\*




#### NOTE: PRINT TEMPLATE AT 100%




#### SURFACE RFID INSTALLATION

Surface Mount: For Door Thickness up to 25mm







#### Power Cable Connection




Pull the power cable through the door opening as shown.





Insert through the rear opening of the battery base as shown.



Connect the power cable as shown above.









**INSTALL GUIDE** Hybrid Smart Lock


#### **3-HOLE TEMPLATE**

Versa™




#### Recommended Tools for Installation (\*Not Included)













#### SURFACE RFID INSTALLATION-CONCEALED PLATE

Surface Mount: For Door Thickness up to 25mm


#### **Required Components**




#### Power Cable Connection





Pull the power cable through the door opening as shown.




Insert through the rear opening of the battery base as shown.











INSTALL GUIDE Hybrid | Smart Lock

#### **4-HOLE TEMPLATE-CONCEALED PLATE**

Versa™






#### **RECESS RFID INSTALLATION**


Recess Mount: For Door Thickness between 10mm-25mm

#### **Required Components**





**Power Cable Connection** 1


Pull the power cable through the door opening as shown.




Insert through the rear opening of the battery base as shown.












#### **MORTISE TEMPLATE**




Recommended Tools for Installation (\*Not Included)













### RECESS RFID INSTALLATION-CONCEALED PLATE

Recess Mount: For Door Thickness between 10mm-25mm


#### **Required Components**




#### Power Cable Connection





Pull the power cable through the door opening as shown.




Insert through the rear opening of the battery base as shown.












#### MORTISE TEMPLATE-CONCEALED PLATE

Versa™




#### Recommended Tools for Installation (\*Not Included)










#### NOTE: PRINT TEMPLATE AT 100%




### SURFACE KEYPAD INSTALLATION

Surface Mount: For Door Thickness less than 10mm


#### **Required Components**




#### Power Cable Connection





Pull the power cable through the door opening as shown.




Insert through the rear opening of the battery base as shown.











**INSTALL GUIDE** Hybrid Smart Lock


#### **3-HOLE TEMPLATE**

Versa™




#### Recommended Tools for Installation (\*Not Included)













#### SURFACE KEYPAD INSTALLATION-CONCEALED PLATE

Surface Mount: For Door Thickness less than 10mm


#### **Required Components**




#### Power Cable Connection




Pull the power cable through the door opening as shown.




Insert through the rear opening of the battery base as shown..




Connect the power cable as shown above.







Rear View



#### 4-HOLE TEMPLATE-CONCEALED PLATE




#### Recommended Tools for Installation (\*Not Included)










#### NOTE: PRINT TEMPLATE AT 100%



#### **RECESS KEYPAD INSTALLATION**


Recess Mount: For Door Thickness less than 10mm

#### **Required Components**





Power Cable Connection


Pull the power cable through the door opening as shown.




Insert through the rear opening of the battery base as shown.












## **RECESS MORTISE TEMPLATE**















#### **RECESS KEYPAD INSTALLATION-CONCEALED PLATE**

Recess Mount: For Door Thickness less than 10mm


#### **Required Components**




# Power Cable Connection




Pull the power cable through the door opening as shown.





Insert through the rear opening of the battery base as shown.



Connect the power cable as shown above.










Versa™

#### RECESS MORTISE TEMPLATE-CONCEALED PLATE




#### Recommended Tools for Installation (\*Not Included)





1 - 15/16" Deep Socket Driver\*




#### NOTE: PRINT TEMPLATE AT 100%




#### SURFACE RFID INSTALLATION

Surface Mount: For Door Thickness less than 10mm


#### **Required Components**




#### Power Cable Connection





Pull the power cable through the door opening as shown.




Insert through the rear opening of the battery base as shown.










Hybrid Smart Lock

#### **3-HOLE TEMPLATE**


Versa™




### SURFACE RFID INSTALLATION-CONCEALED PLATE

Surface Mount: For Door Thickness less than 10mm


#### **Required Components**




### Power Cable Connection





Pull the power cable through the door opening as shown.




Insert through the rear opening of the battery base as shown.












Versa<sup>™</sup> INSTALL GUIDE Hybrid | Smart Lock

#### 4-HOLE TEMPLATE-CONCEALED PLATE




#### Recommended Tools for Installation (\*Not Included)










#### NOTE: PRINT TEMPLATE AT 100%




Recess Mount: For Door Thickness less than 10mm


#### **Required Components**




Power Cable Connection




Pull the power cable through the door opening as shown.





Insert through the rear opening of the battery base as shown.




Connect the power cable as shown above.









#### **MORTISE TEMPLATE**



Recommended Tools for Installation (\*Not Included)










#### **RECESS RFID INSTALLATION-CONCEALED PLATE**


Recess Mount: For Door Thickness less than 10mm

#### **Required Components**




Power Cable Connection


Pull the power cable through the door opening as shown.





Insert through the rear opening of the battery base as shown.



Connect the power cable as shown above.










#### MORTISE TEMPLATE-CONCEALED PLATE

Versa™




#### Recommended Tools for Installation (\*Not Included)





1 - 15/16" Deep Socket Driver\*



#### NOTE: PRINT TEMPLATE AT 100%







#### WARRANTY

LIMITED WARRANTY. Company warrants to the original purchaser of Product manufactured by Company to be free of defects in material and workmanship, provided: (1) Company has been notified of such defects within two years of purchase date and been given the opportunity of inspection by return of any alleged defective Product to Company, or its authorized distributor, free and clear of liens, encumbrances, transportation prepaid, accompanied by the statement of defects and proof of purchase; and (2) Product has not been subject to modification, abuse, misuse, mishandling, misapplication, neglect (including but not limited to improper maintenance), accident, improper installation, alteration and/or modification (including but not limited to use of unauthorized parts or attachments), disassembly, or adjustment or repair performed by anyone other than an authorized service personnel during such period; and (3) such defect has not been caused by corrosion or ordinary wear and tear. This warranty does not cover batteries, normal wear and tear of parts and/or damage resulting from any of the following: negligent use or misuse of product, use of improper voltage or current, and/ or use contrary to operating instructions. The exclusive remedy shall not be deemed to have failed of its essential purpose so long as Company is willing and able to repair or replace non-conforming Product in the prescribed manner.

Unless the product is listed as IP55 rated or otherwise expressed by Company on the sales order acknowledgement, Product is not designed or intended for exterior use or where exposed to moisture. Any use where Product is exposed to moisture is not covered by any warranties and voids any warranties and any resulting damage caused by direct exterior exposure or moisture is at the Buyer's own risk.

The liability of Company for any breach of the foregoing warranty shall not extend to dismantling, installing or reinstalling, but shall be limited to repairing or replacing said items, as Company's option, within a reasonable time after receipt of written notice from Buyer, within the period of time stipulated herein, of any such non-conforming Product, provided that (i) such notice is given immediately upon the detection of such non-conformance and (ii) such notice is received within the time period stipulated herein. BUYER AND COMPANY EXPRESSLY AGREE THAT THE BUYER'S SOLE AND EXCLUSIVE REMEDY AGAINST COMPANY SHALL BE FOR THE REPAIR OR REPLACEMENT (AT COMPANY'S OPTION) OF NON-CONFORMING PRODUCT AS PROVIDED HEREIN.

COMPANY SPECIFICALLY DISCLAIMS ANY OTHER WARRANTIES, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE AND THE IMPLIED WARRANTY OF MERCHANTABILITY, AND COMPANY ALSO SPECIFICALLY DISCLAIMS ANY LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES. IN NO EVENT SHALL COMPANY BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THIS AGREEMENT (INCLUDING BUT NOT LIMITED TO BREACH OF ANY OBLIGATION IMPOSED ON COMPANY HEREUNDER OR IN CONNECTION HEREWITH) OR THE USE, STORAGE, DISPOSAL OR HANDLING OF PRODUCT. Consequential damages for purposes hereof shall include, without limitation, loss of use, income or profit, shutdown, slowdown or stoppage of any production line or facility, or losses sustained as the result of injury (including death) to any person, or loss of or damage to property (including without limitation property handled or processed by the use of Product). Buyer shall indemnify Company against all liability, cost or expense which may be sustained by Company on account of any such loss, damage or injury.

Company will not evaluate warranted Product without Buyer obtaining a Return Merchandise Authorization (RMA) number from Company. Such returns must be prominently marked with the RMA number and shipped prepaid.

Company makes no other warranty, and the warranty is limited to the duration of the expressed warranty period as set forth above.

NOTE: Should Product be considered a consumer product as may be covered by the Magnusson Moss Federal Warranty Act, please be advised that: (1) some states do not allow limitations on incidental consequential damages or how long an implied warranty lasts so that the above limitations may not fully apply; (2) this warranty gives specific legal rights, and a buyer may also have other rights which may vary from state to state.

LIMITATION OF LIABILITY. Company's maximum liability for any damages resulting from or caused by Product, whether in contract, tort, or otherwise, is limited to the purchase price of Product. In no event shall Company be liable for any consequential damages of any nature arising from the sale or use of Product, whether in contract, tort or otherwise, by either use or purchase of Product, the user or purchaser agrees to this limit on Company's liability. Company is not responsible for any modification, addition or alteration to Product by others.

Company reserves the right to make changes in designs and specifications or to make additions or improvements on its products without notice and without incurring any obligation to incorporate them on products previously manufactured.

#### **CONTACT INFORMATION**